

7.1 Gloves

When chemotherapy gloves are required, they must meet American Society for Testing and Materials (ASTM) standard D6978 (or its successor).

Chemotherapy gloves should be worn for handling all HDs including non-antineoplastics and for reproductive risk only HDs. Chemotherapy gloves must be powder-free because powder can contaminate the work area and can adsorb and retain HDs. Gloves must be inspected for physical defects before use. Do not use gloves with pin holes or weak spots. When used for sterile compounding, the outer chemotherapy gloves must be sterile. Chemotherapy gloves should be changed every 30 minutes unless otherwise recommended by the manufacturer's documentation and must be changed when torn, punctured, or contaminated. Hands must be washed with soap and water after removing gloves.

[Reference: USP <800> General Chapter 2020](#)